


Ω MEGA[®]

Door Frame Products Inc.

Aluminum Interior Frames



1222 Ardmore Ave., Itasca, IL 60143
Phone: 630.773.9900 Fax: 800.932.9224
www.omegamfg.com
e-mail: omegainfo@omegamfg.com

INDEX

<u>PAGE #</u>	<u>DESCRIPTION</u>
2	ILLUSTRATION OF OF VARIOUS PROFILES WITH TRIMS
3	ILLUSTRATION OF DOOR FRAME WITH VARIOUS TRIMS
4	ILLUSTRATION OF DOOR / WINDOW GASKET & MOUNTING CLIPS
5	ILLUSTRATION OF OPTIONAL STANDARD & EXTENDED DOOR STRIKES
6	ILLUSTRATION OF OPTIONAL DUST BOX
7	SPECIFICATIONS
8	SPECIFICATIONS CONTINUED
9	FINISHES AND FIRE RATINGS
10	STANDARD BUTT LOCATIONS FOR 1 & 1-1/2 PAIR
11	STANDARD BUTT LOCATIONS FOR 2 PAIR, 80" & 84" DUTCH DOOR
12	HINGE OFFSET DIMENSIONS
13	ASA OFFSET DIMENSIONS
14	3-1/2" WALL SYSTEM - DOOR FRAME SECTION & HEAD & JAMB WINDOW SECTION
15	3-1/2" WALL SYSTEM - SILL WINDOW SECTION & REGLET 2" SECTION
16	3-1/2" WALL SYSTEM - CASE OPENING SECTION & REGLET 1-1/2" SECTION
17	3-1/2" WALL SYSTEM - "U" CHANNEL SECTION 2" & 4" WINDOW SILL STARTER
18	3-1/2" WALL OR SILL STARTER
19	3-1/2" CORNER POST
20	3-3/4" WALL SYSTEM - DOOR FRAME SECTION & HEAD & JAMB WINDOW SECTION
21	3-3/4" WALL SYSTEM - SILL WINDOW SECTION & REGLET 2" SECTION
22	3-3/4" WALL SYSTEM - CASE OPENING SECTION & REGLET 1-1/2" SECTION
23	3-3/4" WALL SYSTEM - "U" CHANNEL SECTION 2" & 4" WINDOW SILL STARTER
24	3-3/4" WALL OR SILL STARTER
25	3-3/4" CORNER POST
26	4-7/8" WALL SYSTEM - DOOR FRAME SECTION & HEAD & JAMB WINDOW SECTION
27	4-7/8" WALL SYSTEM - SILL WINDOW SECTION & REGLET 2" SECTION
28	4-7/8" WALL SYSTEM - CASE OPENING SECTION & REGLET 1-1/2" SECTION
29	4-7/8" WALL SYSTEM - "U" CHANNEL SECTION 2" & 4" WINDOW SILL STARTER
30	4-7/8" WALL OR SILL STARTER
31	4-7/8" CORNER POST
32	5-1/4" WALL SYSTEM - DOOR FRAME SECTION & HEAD & JAMB WINDOW SECTION
33	5-1/4" WALL SYSTEM - SILL WINDOW SECTION & REGLET 2" SECTION
34	5-1/4" WALL SYSTEM - CASE OPENING SECTION & REGLET 1-1/2" SECTION
35	5-1/4" WALL SYSTEM - "U" CHANNEL SECTION 2" & 4" WINDOW SILL STARTER
36	5-1/4" WALL OR SILL STARTER
37	5-1/4" CORNER POST
38	7-1/4" WALL SYSTEM - DOOR FRAME SECTION & 3" TO 7-1/2" ADJUSTABLE DOOR FRAME SECTION
39	3" TO 7-1/2" ADJUSTABLE LITE SYSTEM & ADJUSTABLE CASE OPENING SYSTEM

INDEX CONTINUED

<u>PAGE #</u>	<u>DESCRIPTION</u>
40	FILLER BAR
41	ILLUSTRATION OF REGULAR ARM REINFORCEMENT WITH VARIOUS TRIMS
42	ILLUSTRATION OF CONCEALED ARM REINFORCEMENT
43	3-1/2" SECTION VIEWS
44	3-1/2" SECTION VIEWS CONTINUED
45	3-3/4" SECTION VIEWS
46	3-3/4" SECTION VIEWS CONTINUED
47	4-7/8" SECTION VIEWS
48	4-7/8" SECTION VIEWS CONTINUED
49	5-1/4" SECTION VIEWS
50	5-1/4" SECTION VIEWS CONTINUED
51	3" TO 7-1/2" ADJUSTABLE SECTION VIEWS
52	SINGLE DOOR FRAME - ORDER FORM
53	SINGLE DOOR FRAME WITH TRANSOM - ORDER FORM
54	CASE OPENING FRAME (3 SIDES) - ORDER FORM
55	SINGLE DOOR FRAME ADJUSTABLE - ORDER FORM
56	PAIR DOOR FRAME - ORDER FORM
57	PAIR DOOR FRAME ADJUSTABLE - ORDER FORM
58	SINGLE DOOR FRAME WITH FULL HEIGHT SIDELITE ONE SIDE - ORDER FORM
59	SINGLE DOOR FRAME WITH PARTIAL SIDELITE ONE SIDE - ORDER FORM
60	BORROWED LITE (WINDOW FRAME) - ORDER FORM
61	CASE OPENING FRAME (4 SIDES) - ORDER FORM
62	BORROWED LITE FROM FLOOR (WINDOW FRAME) - ORDER FORM
63	DOOR FRAME WITH SIDELITE AND TRANSOM - ORDER FORM
64	DOOR FRAME ROUGH OPENING INSTRUCTIONS
65	WINDOW FRAME ROUGH OPENING INSTRUCTIONS
66	DOOR FRAME INSTALLATION INSTRUCTIONS
67	WINDOW FRAME INSTALLATION INSTRUCTIONS
68	WINDOW FRAME INSTALLATION INSTRUCTIONS CONTINUED
69	SIDELITE INSTALLATION INSTRUCTIONS
70	SIDELITE INSTALLATION INSTRUCTIONS CONTINUED
71	20 MINUTE DOOR FRAME & POSITIVE PRESSURE INSTALLATION INSTRUCTIONS
72	ALUMINUM DOOR
73	EXIT DEVICE